




GAS RANGE
Fingerprint Resistant

MODELS:

WFG535S0LZ5 (Stainless)

COOKTOP PARTS




COOKTOP PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts
	W11508883	Wiring Diagram
	W11426600	Owner's Manual
	W11530282	Quick Start Guide
2		Burner Cap Kit
	W11395131	Black (Set of 4)
3	W11367107	Burner Kit
4		Cooktop
	W11418086	Black

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
5		Panel, Manifold
	W11044911	Stainless
6		Knob, Control
	W11510456	Stainless
7		Grate Kit
	W11090908	Black (Set of 3)
8	W10673618	Screw
9	3196557	Screw
10	W11379945	Bracket, Anti-Tip

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
11	7101P485-60	Screw, Anti-Tip Kit
		FOLLOWING PARTS NOT ILLUSTRATED
	W11457191	Harness, Main
	W11450461	Harness, Bake and Broil
	3196520	Clip, Wire
	W10334923	Clip, Gas Wiring
	313438	Clip, Harness
	3196896	Clip, Wire


CONTROL PANEL PARTS



CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Endcap	7	8523412	Bracket, Rear Cooktop	15	W10797001	Bracket, Ignitor
	W11130372	Black (Left)	8	W10198745	Cover, Upper	16	W11350452	Spark Module
	W11130379	Black (Right)	9	W10192841	Shield, Heat	17	3196165	Screw
2	8053505	Shield, Heat	10	W10184251	Cover, Back			
3		Panel, Control	11	3196169	Screw			
	W10835288	Stainless	12		Control, Electronic (LCX)			
4	W10762981	Bracket, Mounting		W11520700	Black			
5	W10920631	Module, Spark DSI	13	3196178	Screw			
6	W10516123	Bracket, Console Mounting	14	W10695491	Bracket, Control			


MANIFOLD PARTS



MANIFOLD PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11577792	Screw, Valve	9	W10224921	Bracket, Aegis	24	W11428831	Electrode (Left Front, Left Rear)
2	W10949105	Bracket, Saddle Valve	10	3196385	Screw		W11428858	Electrode (Right Front, Right Rear, Center)
3	W11459257	Orifice Holder Assembly (15K) (Left Front)	11	3400016	Screw			FOLLOWING PARTS NOT ILLUSTRATED
	W11459258	Orifice Holder Assembly (9.5K) (Left Rear)	12	8054078	Burner, Broiler		W11489399	LP 5 Orifice Conversion Kit
	W11459260	Orifice Holder Assembly (15K) (Right Front)	13	W10184491	Spreader, Flame (Oven)		W10566537	LP Bake and Broil Kit
	W11459259	Orifice Holder Assembly (5K) (Right Rear)	14	9758078	Burner, Bake		W10400495	Orifice, LP Bake
	W11459261	Orifice Holder Assembly (8K) (Center)	15	W11370883	Regulator		W10465080	Orifice, LP Broil
4	W10215439	Tubing (Manifold to Regulator)	16	W10333842	Electrode, Broil		W10182767	Tie, Manifold Wire
5	W11537754	Harness, Igniter (Includes Switches)	17	W10420040	Tube, Broiler Supply			
6	W11450459	Electrode, Bake	18	W11435700	Fitting, Broiler			
7	W11510000	Manifold Assembly	19	W11485872	Orifice (15K) (Left Front and Right Front)			
8	W11509685	Valve, Gas (Left Front and Right Front)		W11485873	Orifice (9.5K) (Left Rear)			
	W11509686	Valve, Gas (Left Rear, Center)		W11485871	Orifice (5K) (Right Rear)			
	W11509687	Valve, Gas (Right Rear)		W11485874	Orifice (8K) (Center)			
			20	W10137062	Spreader, Flame (Broiler)			
			21	3196265	Screw			
			22	W10362924	Screw			
			23	W10827923	Electrode, Spring			


CHASSIS PARTS



CHASSIS PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11457094	Box, Flue	17	9757239	Rod, Door Switch	33	W10674705	Glide, Drawer Front
2	8272747	Shield, Flue	18	W10031780	Screw	34	3196178	Screw
3	W11379351	Box-Burner, Gas Sealed	19	3400080	Screw	35	W11173792	Rack, Oven
4		Panel, Side	20	W10158780	Cover, Rear Fan	36	W11403615	Fan Motor, Convection
	W10162245	Black	21	W11491751	Seal, Door	37	W11425715	Blade, Fan
5	W10137382	Clip, Panel	22	W10435470	Brace, Main Back	38	W11433702	Nut, Acorn (LH)
6	8523249	Bracket, Manifold	23	W11379353	Retainer, Insulation (Left)	39	4449809	Screw
7	W10362924	Screw		W11379943	Retainer, Insulation (Right)	40	W10134126	Bracket, Fan
8	3196560	Screw				41	W10134124	Cover, Conv Fan
9	W10341186	Front Foot Assembly	24	3196560	Screw	42	W11661815	Basket, Airfry
10	W10058460	Foot, Leveling	25	W10910642	Cord, Power			FOLLOWING PARTS NOT ILLUSTRATED
11	3195097	Bottom, Oven	26	W10289077	Receiver, Hinge		8524099	Insulation, Wrap
12	W10586204	Sensor	27	W11511828	Switch, Door		W10180437	Insulation, Back
13	8053967	Baffle, Burner Oven	28	W11634772	Light Assembly			
14	8053969	Shield, Heat	29	W10571723	Bulb, Halogen 40 Watts			
15	8053968	Shield, Lower	30	9761013	Front Door Latch Assembly			
16	W10390008	Base Rail Assembly (Left)	31	W10078370	Rod, Push Latch			
	W10390007	Base Rail Assembly (Right)	32	W10107820	Rear Door Latch Assembly			

DOOR PARTS




DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Handle and Vent Assembly
	W11242950	Stainless
2	W10480830	Screw
3		Trim, Lower Door
	W11444043	Black
4	9761344	Liner, Door
5	W10031790	Screw
6	W11044424	Glass, Inner
7	W10316950	Frame, Glass

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
8	W10278991	Insulation, Door Strip
9	W11380222	Retainer, Insulation
10	W10299224	Hinge, Active (With Spring)
11		Glass, Outer Door
	W10884159	Black
12		Trim, Door
	W10746436	Black (Left)
	W10746435	Black (Right)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
13	W10327235	Screw
14	W11379944	Strap, Door
15	W10299227	Hinge, Door (Passive)
16	W10884775	Badge
17	W10200660	Screw

DRAWER PARTS



DRAWER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10674708	Glide, Drawer Rear	4		Panel, Drawer Front
2	W10688022	Drawer, Storage		W11190210	Stainless
3	W10462909	Bracket, Mounting	5	3196169	Screw

OPTIONAL PARTS (NOT INCLUDED)

REFINISHING MATERIAL

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	242756	Oven Liner Touch Up Paint

INSULATION

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	261514	Insulation (1-1/2 x 24 x 120 in)
	240132	Insulation (2-1/2 x 22 x 120 in)

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	4392899	Biscuit and Bisque
	72017	White
	511873	White Porcelain (2 oz.)

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	285006	Black
	350930	White

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

ACCESSORY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	W10355016	Cleaner, Stainless Steel
	4396096RB	Griddle
	4396923	Broiler Pan and Grid
	W10123240	Rack, Broiler Pan and Roasting