




GAS RANGE

MODELS:

WFG525S0JB6 (Black)
WFG525S0JW6 (White)


COOKTOP PARTS



COOKTOP PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	7		Grate Kit	12	W10673618	Screw
	W11426600	Owner's Manual		W11090908	Black (Set of 3)			FOLLOWING PARTS NOT ILLUSTRATED
	W11428051	Quick Start Guide	8	W11352018	Spreader, Flame (Left Front, Right Front)		W11457167	Harness, Main
	W11508882	Wiring Diagram		W11352020	Spreader, Flame (Right Rear)		W11450461	Harness, Bake and Broil
2		Burner Cap Kit		W11352021	Spreader, Flame (Left Rear)		3196520	Clip, Wire
	W11395131	Black (Set of 4)		W11357363	Oval Burner Assembly (Center)		W10334923	Clip, Gas Wiring
3	W11367107	Burner Kit					313438	Clip, Harness
4		Cooktop					3196896	Clip, Wire
	W11418086	Black					3196173	Screw
	W11418084	White						(Grounding)
5		Panel, Manifold	9	3196557	Screw		W10182767	Tie, Manifold Wire
	W11089578	Black	10	W11379945	Bracket, Anti-Tip			
	W11089577	White	11	7101P485-60	Screw, Anti-Tip Kit			
6		Knob, Control						
	W11510457	Black						
	W11510458	White						


CONTROL PANEL PARTS



CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Endcap	5	W10920631	Module, Spark DSI	12		Control, Electronic (LCX)
	W11130372	Black (Left)	6	W10516123	Bracket, Console Mounting		W11520699	Black
	W11130379	Black (Right)					W11520697	White
	W11130371	White (Left)	7	8523412	Bracket, Rear Cooktop	13	3196178	Screw
	W11130378	White (Right)	8	W10198745	Cover, Upper	14	W10695491	Bracket, Control
2	8053505	Shield, Heat	9	W10192841	Shield, Heat	15	W10797001	Bracket, Ignitor
3		Panel, Control	10	W10184370	Cover, Back	16	W11350452	Spark Module
	W10885611	Black	11	3196169	Screw	17	3196165	Screw
	W10885610	Black						
4	W10762981	Bracket, Mounting						


MANIFOLD PARTS



MANIFOLD PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11577792	Screw, Valve	9	W10224921	Bracket, Aegis	24	W10827923	Electrode, Spring
2	W10949105	Bracket, Saddle Valve	10	3196385	Screw			FOLLOWING PARTS NOT ILLUSTRATED
3	W11459257	Orifice Holder Assembly (15K)	11	3400016	Screw			
		(Left Front)	12	8054078	Burner, Broiler	W11489399		LP 5 Orifice Conversion Kit
	W11459258	Orifice Holder Assembly (9.5K)	13	W10184491	Spreader, Flame (Oven)	W10566537		LP Bake and Broil Kit
		(Left Rear)	14	9758078	Burner, Bake	W10400495		Orifice, LP Bake
	W11459260	Orifice Holder Assembly (15K)	15	W11370883	Regulator	W10465080		Orifice, LP Broil
		(Right Front)	16	W10333842	Electrode, Broil			
	W11459259	Orifice Holder Assembly (5K)	17	W10420040	Tube, Broiler Supply			
		(Right Rear)	18	W11435700	Fitting, Broiler			
	W11459261	Orifice Holder Assembly (8K)	19	W11485872	Orifice (15K)			
		(Center)		W11485873	Orifice (9.5K)			
4	W10215439	Tubing (Manifold to Regulator)		W11428753	Orifice (15K)			
5	W11537754	Harness, Igniter (Includes Switches)		W11485871	Orifice (5K)			
6	W11450459	Electrode, Bake		W11485874	Orifice (8K)			
7	W11510000	Manifold Assembly			(Center)			
8	W11509685	Valve, Gas	20	W10137062	Spreader, Flame (Broiler)			
		(Left Front and Right Front)	21	3196265	Screw			
	W11509686	Valve, Gas	22	W10362924	Screw			
		(Left Rear, Center)	23	W11428831	Electrode			
	W11509687	Valve, Gas			(Left Front, Left Rear, Center)			
		(Right Rear)		W11428858	Electrode			
					(Right Front, Right Rear)			


CHASSIS PARTS



CHASSIS PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11457094	Box, Flue	14	8053969	Shield, Heat	25	W10910642	Cord, Power
2	8272747	Shield, Flue	15	8053968	Shield, Lower	26	W10289077	Receiver, Hinge
3	W11379351	Box-Burner, Gas Sealed	16	W10390008	Base Rail Assembly (Left)	27	W11511828	Switch, Door
4		Panel, Side		W10390007	Base Rail Assembly (Right)	28	W11634772	Light Assembly
	W10162245	Black				29	W10571723	Bulb, Halogen 40 Watts
	W10575396	White	17	9757239	Rod, Door Switch	30	9761013	Front Door Latch Assembly
5	W10137382	Clip, Panel	18	W10031780	Screw	31	W10078370	Rod, Push Latch
6	8523249	Bracket, Manifold	19	3400080	Screw	32	W10107820	Rear Door Latch Assembly
7	W10362924	Screw	20	W11173792	Rack, Oven	33	W10674705	Glide, Drawer Front
8	3196560	Screw	21	W11491751	Seal, Door	34	3196178	Screw
9	W10341186	Front Foot Assembly	22	W10435470	Brace, Main Back			FOLLOWING PARTS NOT ILLUSTRATED
10	W10058460	Foot, Leveling	23	W11379353	Retainer, Insulation (Left)			
11	3195097	Bottom, Oven		W11379943	Retainer, Insulation (Right)		8524099	Insulation, Wrap
12	W10586204	Sensor					W10180437	Insulation, Back
13	8053967	Baffle, Burner Oven	24	3196560	Screw			

DOOR PARTS




DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Handle and Vent Assembly
	W11242949	Black
	W11242947	White
2		Trim, Lower Door
	W11444043	Black
	W11444042	White
3	9761344	Liner, Door
4	W10031790	Screw
5	W10031780	Screw
6	W11044424	Glass, Inner
7	W10316950	Frame, Glass

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
8	W10278991	Insulation, Door Strip
9	W11380222	Retainer, Insulation
10	W10299226	Hinge, Active
11		Glass, Outer Door
	W11687920	Black
	W10409945	White
12		Trim, Door
	W10746436	Black (Left)
	W10746435	Black (Right)
	8523172	White (Left)
	8523166	White (Right)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
13	W10327235	Screw
14	W11379944	Strap, Door
15	W10299227	Hinge, Door (Passive)
16	W10884775	Badge
17	W10200660	Screw
18	W10480830	Screw

DRAWER PARTS



DRAWER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Panel, Drawer Front	3	W10462911	Bracket, Mounting	6		Rivet, Push
	W11123976	Black	4	3196169	Screw		3196813	Black
	W11123977	White	5	W10674708	Glide, Drawer Rear		3196814	Rivet, Plastic (WHITE)
2	W10688022	Drawer, Storage						

OPTIONAL PARTS (NOT INCLUDED)

REFINISHING MATERIAL

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	242756	Oven Liner Touch Up Paint

INSULATION

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	261514	Insulation (1-1/2 x 24 x 120 in)
	240132	Insulation (2-1/2 x 22 x 120 in)

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	4392899	Biscuit and Bisque
	72017	White
	511873	White Porcelain (2 oz.)

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	285006	Black
	350930	White

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

ACCESSORY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	W10355016	Cleaner, Stainless Steel
	4396096RB	Griddle
	4396923	Broiler Pan and Grid
	W10123240	Rack, Broiler Pan and Roasting