




GAS RANGE

MODELS:

MGR6600FB6 (Black)
MGR6600FW6 (White)


COOKTOP PARTS



COOKTOP PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	5		Panel, Manifold	14	W11368533	Burner Kit
	W11427471	Quick Start Guide		W10724449	Black			FOLLOWING PARTS NOT ILLUSTRATED
	W11450808	Owners Manual		W10724448	White			
	W11326825	Tech Sheet	6		Knob, Control		W11457167	Harness, Main
2		Kit, Burner Cap		W11510309	Black		W11450461	Harness, Bake/Broil
	W11498499	Black (Set of 4)		W11510308	White		W10182767	Tie, Manifold Wire
3	W11352018	Spreader, Flame (Left Front & Right Front)	7		Grate Kit		3196520	Clip, Wire
	W11352020	Spreader, Flame (Right Rear)		W10911970	Black		3196896	Clip, Wire
	W11352021	Spreader, Flame (Left Rear)	8	W10673618	Screw		W10334923	Clip, Gas Wiring
			9	3196557	Screw		313438	Clip, Harness
			10	W11379945	Bracket, Anti-Tip			
			11	7101P485-60	Screw, Anti-Tip Kit			
4		Cooktop	12		Bezel			
	W11418086	Black		W10894849	Black			
	W11418084	White		W10894848	White			
			13	W11367086	Spreader, Flame			

CONTROL PANEL PARTS




CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Endcap
	W11130372	Black (Left)
	W11130379	Black (Right)
	W11130371	White (Left)
	W11130378	White (Right)
2	8053505	Shield, Heat
3		Panel, Control
	W10885611	Black
	W10885610	White
4	W10762981	Bracket, Mounting
5	W10920631	Module, Spark DSI

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
6	W10516123	Bracket, Console Mounting
7	8523412	Bracket, Rear Cooktop
8	W10198745	Cover, Upper
9	W10192841	Shield, Heat
10	W10184370	Cover, Back
11	3196169	Screw
12		Control, Electronic (LCX)
	W11520695	Black
	W11520696	White

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
13	3196178	Screw
14	W10695491	Bracket, Control
15	W10475149	Module, Spark (5+0)
16	W10797001	Bracket, Ignitor


MANIFOLD PARTS



MANIFOLD PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11577792	Screw, Valve	8	W11509685	Valve, Gas (Left Front & Right Front)	20	W10137062	Spreader, Flame (Broiler)
2	W10949105	Bracket, Saddle Valve				21	3196265	Screw
3	W11459257	Orifice Holder Assembly (15K) (Left Front)		W11509686	Valve, Gas (Left Rear, Center)	22	W10362924	Screw
	W11459258	Orifice Holder Assembly (9.5K) (Left Rear)		W11509687	Valve, Gas (Right Rear)	23	W11428831	Electrode (Left Front, Left Rear)
	W11459260	Orifice Holder Assembly (15K) (Right Front)	9	W10224921	Bracket, Aegis		W11428858	Electrode (Right Front, Right Rear, Center)
	W11459259	Orifice Holder Assembly (5K) (Right Rear)	10	3196385	Screw	24	W10827923	Electrode, Spring
	W11459261	Orifice Holder Assembly (8K) (Center)	11	3400016	Screw			FOLLOWING PARTS NOT ILLUSTRATED
4	W10215439	Tubing (Manifold to Regulator)	12	8054078	Burner, Broiler		W11489399	LP 5 Orifice Conversion Kit
5	W11537754	Harness, Igniter (Includes Switches)	13	W10184491	Spreader, Flame (Oven)		W10566537	LP Bake and Broil Kit
6	W11450459	Electrode, Bake	14	9758078	Burner, Bake		W10400495	Orifice, LP Bake
7	W11510000	Manifold Assembly	15	W11370883	Regulator		W10465080	Orifice, LP Broil
			16	W10333842	Electrode, Broil			
			17	W10420040	Tube, Broiler Supply			
			18	W11435700	Fitting, Broiler			
			19	W11485872	Orifice (15K) (Left Front & Right Front)			
				W11485873	Orifice (9.5K) (Left Rear)			
				W11485871	Orifice (5K) (Right Rear)			
				W11485874	Orifice (8K) (Center)			


CHASSIS PARTS



CHASSIS PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11457094	Box, Flue	15	8053968	Shield, Lower	27	W11511828	Switch, Door
2	8272747	Shield, Flue	16	W10390008	Base Rail Assembly (Left)	28	W11544377	Light Assembly
3	W11379351	Box-Burner, Gas Sealed		W10390007	Base Rail Assembly (Right)	29	W10571723	Bulb, Halogen 40 Watts
4		Panel, Side	17	9757239	Rod, Door Switch	30	9761013	Front Door Latch Assembly
	W10162245	Black	18	W10031780	Screw	31	W10078370	Rod, Push Latch
	W10575396	White	19	W10379120	Screw	32	W10107820	Rear Door Latch Assembly
5	W10137382	Clip, Panel	20	3400080	Screw	33	W10674705	Glide, Drawer Front
6	8523249	Bracket, Manifold	21	W11491751	Seal, Door	34	3196178	Screw
7	W10362924	Screw	22	W10435470	Brace, Main Back	35	W11173792	Rack, Oven
8	3196560	Screw	23	W11379353	Retainer, Insulation (Left)			FOLLOWING PARTS NOT ILLUSTRATED
9	W10341186	Front Foot Assembly		W11379943	Retainer, Insulation (Right)		8524099	Insulation, Wrap
10	W10058460	Foot, Leveling	24	3196560	Screw		W10180437	Insulation, Back
11	3195097	Bottom, Oven	25	W10624590	Cord, Power			
12	W10586204	Sensor	26	W10289077	Receiver, Hinge			
13	8053967	Baffle, Burner Oven						
14	8053969	Shield, Heat						


DOOR PARTS



DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10031790	Screw	10	9761357	Retainer, Insulation	17	W10327235	Screw
2	9761344	Liner, Door	11	W10480830	Screw	18	W10299226	Hinge, Active
3	W10278991	Insulation, Door Strip	12		Glass, Window	19		Trim, Door
4	W10200660	Screw		W10884159	Black		W10746435	Black (Right)
5	W10299227	Hinge, Door (Passive)		W10409945	White		8523166	White (Right)
6	W10612925	Badge	13		Trim, Oven Door Vent			
7		Trim, Lower Door		W10875233	Black			
	W11444043	Black		W10875232	White			
	W11444042	White	14	W11379944	Strap, Door			
8	9758162	Glass, Inner	15		Trim, Door			
9		Handle, Oven Door		W10746436	Black (Left)			
	W10889624	Black		8523172	White (Left)			
	W10889625	White	16	W10316950	Frame, Glass			

DRAWER PARTS



DRAWER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Panel, Drawer	3	W10688022	Drawer, Storage	6		Rivet, Push
	W11123976	Black	4	W10674708	Glide, Drawer Rear		3196813	Black
	W11123977	White	5	W10462911	Bracket, Mounting		3196814	White
2	3196165	Screw						

OPTIONAL PARTS (NOT INCLUDED)

REFINISHING MATERIAL

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	242756	Oven Liner Touch Up Paint

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	4392899	Biscuit/Bisque
	511873	White Porcelain (2 oz.)

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

INSULATION

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	261514	Insulation (1-1/2" x 24" x 120")
	240132	Insulation (2-1/2" x 22" x 120")

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	285006	Black

ACCESSORY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	W10355016	Cleaner, Stainless Steel
	4396096RB	Griddle
	4396923	Broiler Pan and Grid
	W10123240	Rack, Broiler Pan & Roasting