



20 CUBIC FOOT FRENCH DOOR BOTTOM MOUNT REFRIGERATOR


MODELS:

KRFC300EWH03 (White)

KRFC300EBL03 (Black)

KRFC300ESS03 (Stainless Steel)


CABINET PARTS



CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	13		Cover, Hinge	22		Assembly, Grille (Includes Clips)
	W11298859	Use and Care Guide			Left Hand			
	W11308939	Energy Guide		W10337634	White		W10534154	White
		Tech Sheet		W10337647	Black		W10534153	Black
	W10787424	English		W10337648	Grey		W10534155	Grey
	W10787423	French	14	12992403	Screw	23	W10317076	Board, HV Control
2	W11046934	Assembly, Fill Tube (Includes Tubing, Fill Tube Elbow, Tube Insert and Clamp)	15		Hinge, Center Right Hand	24		Hinge, Center Left Hand
				W10740144	White		W10740148	White
				W10740145	Black		W10740149	Black
				W10740146	Grey		W10740150	Grey
3	12698403	Plate, Pivot	16	W10658542	Block, Fill Tube	25	W10141645	Screw
4	W11534848	Gasket	17		Cover, Corner	26	12726003	Cover, Water Line
5		Assembly, Roller		12587703W	White	27	W10208593	Guard, Dual Water Valve
	W10515763	Left Hand		12587703B	Black			
	W10515762	Right Hand		12587703AP	Grey	28	688983	Screw
6	W10528513	Sweep, Dual Tube	18		Hinge, Top	29	12990504	Screw
7	A3076901	Plug, Button		12963204ED	Left Hand	30	W10211855	Cover, Unit
8	12961602	Cover, Control Box	19		Cabinet (Not A Serviceable Part)	31	W10420083	Valve, Water Inlet
9	12992602	Screw	20	W10709365	Screw	32	M0108107	Clamp, Tube
10		Cover, Hinge	21		Shim, Hinge	33	W10141622	Brake, Roller
		Right Hand		12999501	Left Hand	34	12957702SP	Lid, HV Box
	12962302W	White		12999502	Right Hand			
	12962302B	Black						
	12962302AP	Grey						
11	W10673840	Screw (Stainless)						
12		Hinge, Top						
	12963205ED	Right Hand						


REFRIGERATOR LINER PARTS



REFRIGERATOR LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	13	12806701	Cover, Damper	24	12568001	Cover, Filter
2	W10464764	Module, Light	14	13012402	Insulation, Damper	25	W11256384	Filter, Water
3	W10632601	Overlay	15	W10594329	Control, Damper	26	12664501SP	Cartridge, Bypass
4	W10464767	Module, Control	16	W11437003	Facade, Dispenser (Top)	27	B8390302	Clip, Facade
5	W10746274	Board, Control	17	61006182	Union, Water	28	12990302	Screw
6	W10847853	Switch, Light	18	W11031909	Guide, Waterline	29	W10163893	Insulation, Tank
7	W11132917	Cover, Light	19	W11097710	Tank, Water	30	12575501	Switch, Limit
8	W10443023	Housing, Light	20	W11437002	Facade, Dispenser	31	W11437528	Plate, Dispenser
9	W11468934	Light Module, LED	21	12990512	Screw	32	W11437004	Foam, Dispenser Plate
10	12251001	Clip, Water Tube	22	12704801	Plate, Filter	33	12791416	Thermistor
11	12806801	Insert, Damper Cover	23	W11308018	Head, Water Filter (Includes Bypass Cartridge)			Following Parts Not Illustrated
12	12990604	Screw					W10224292	Harness, Controls (Refrigerator)


FREEZER LINER AND ICEMAKER PARTS



FREEZER LINER AND ICEMAKER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	14	W10277025	Module, Light	27	W10662407	Assembly, Drain Funnel
2	A3189392	Gasket, Foam	15	13058002	Clip, Evaporator Motor	28	M0500703	Seal
3	12002497	Gear	16	W10847849	Switch, Light	29	B8381501	Gasket, Drain
4		Rack, Side	17	12791419SP	Thermistor	30	12815301	Cover, Thermistor
	W11310677	Left Hand	18		Cradle, Basket	31	W10171529N	Pan, Ice
	W11310678	Right Hand		W10281115	Left Hand	32	W10793298	Assembly, Icemaker (Complete)
5	W10802332	Shaft, Rack		W10281116	Right Hand			
6	12990501	Screw	19	13055901	Slide, Drawer	33	W11260635	Arm, Shut Off
7	W10157765	Diverter, Air	20	A3189396	Gasket	34	W10793621	Harness, Icemaker Wire
8	12990521	Screw	21		Adapter, Side			
9	W11468934	Light Module, LED		W10284692	Left Hand	35	W10289690	Cover, Icemaker
10	W11448709	Guide, Fill Tube		W10284693	Right Hand			
11	W10308416	Cover, Evaporator	22	13024803	Grille, Freezer Air			
12	12990511	Screw	23	13057901	Shroud, Evaporator Fan			
13		Bracket, Door	24	2169142	Blade, Fan			
	W10330994	Left Hand	25	W10150583	Grommet, Fan Motor			
	W10330995	Right Hand	26	13062901	Motor, Evaporator			


REFRIGERATOR DOOR PARTS



REFRIGERATOR DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Left	11	W10289497	Bucket, Gallon	17		Latch, Door Closer
	13107888W	White	12		Mullion, Door			Left Hand
	13107888B	Black		12722803W	White		W10833740	White
	13107888S	Stainless		12722803B	Black		W10725268	Black
2	12804701SP	Door, Dairy		12732501AP	Grey		W10833741	Grey
3	12744905	Assembly, Dairy	13		Closure, Door	18		Latch, Door Closer
4	12369502SP	Tray, Dairy		12028505W	White			Right Hand
5	W10371194	Bucket, Medium		12028505B	Black		W10833738	White
6	12990204	Screw		12028505AP	Grey		W10725267	Black
7	W11328753	Screw	14		Stop, Door		W10833739	Grey
8		Gasket, Door		12968202W	White	19	12990518	Screw
	W10830189	White		12968202B	Black	20	12996601	Clip, Bushing
	W10830206	Black		12968202AP	Grey			
	W10830162	Grey	15	12990504	Screw			
9		Handle, Door	16		Door, Right			
	W11339136	Stainless		13107887W	White			
10	W10450021	Gripper, Medium		13107887B	Black			
	W10449760	Gripper, Gallon		13107887S	Stainless			

FREEZER DOOR PARTS




FREEZER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Freezer
	12977879W	White
	12977878B	Black
	12977880S	Stainless
2		Handle, Door
	W11222206	Stainless

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
3		Gasket, Door
	W10443319	White
	W10436252	Black
	W10443320	Grey
4	W11328753	Screw
5		Nameplate
	W10765861	Grey


UNIT PARTS



UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	12992301	Screw	18	W10346415	Condenser	34	2169104	Insulation, Sound Deadening
2	12825803	Blade, Fan	19	W10281329	Clip, Drier			
3	W10480111	Basepan	20	W10292803	Tray, Drip	35	W10815863	Clip, Condenser
4	12990511	Screw	21	12990701	Screw			Following Parts Not Illustrated
5	W10350564	Capacitor	22	W10669255	Evaporator		978025	Valve, Access (1/4")
6	W10233569	Tube, Discharge	23	W11244122	Gasket, Foam		978026	Valve, Access (5/16")
7	W11174745	Harness, Evaporator Heater	24	W11373924	Motor, Condenser Fan		978027	Valve, Access (3/8")
8	W10655368	Pan, Drain	25	10428101	Clip, Heater		978029	Valve, Access (5/8")
9	W10622701	Screw	26	W11224411	Harness, Unit (Includes Power Cord)		978030	Valve, Access (3/4")
10	12729123	Heater, Defrost	27	W10177049	Drier		876764	Valve, Access (3/16")
11	W10216075	Strap, Bale	28	W10879296	Compressor			REFRIGERANT CHARGE
12	W10796752	Device, Start	29	10623002	Clip, Evaporator			5.00 oz. (R-134A)
13	W10137529	Grommet, Condenser	30	12477202	Axle, Roller			
14	2319835	Grommet, Condenser	31	W11463236	Shroud, Condenser Fan			
15	12477102	Roller	32	W10236396	Strap, Compressor			
16	12992101	Screw	33	W10622099	Extension, Drain Tube			
17	10835903	Grommet						

SHELF PARTS



SHELF PARTS

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10893771	Glass, Pantry
2	12802602SP	Front, Crisper Pan
3	W10742811	Rack, Wine
4	W10528935	Support, Glass
5	12227305WH	Brace, Pantry
6	12531901	Track, Deli Drawer
7	12727304	Tray, Lower Basket
8	W10241046	Divider, Basket (Upper)
9	12656901	Gasket, Pantry
10	12656202	Housing, Control
11	W10878953	Assembly, Fixed Top Shelf
12	12655402	Slide, Temperature Control
13	W10878945	Assembly, Shelf
14	W10235370	Glide, Pantry
15	12990504	Screw

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
16		Track, Pantry
	12656105	Left Hand
	12656018	Right Hand
17	12531105SP	Pan, Crisper
18	W10832723	Brace, Crisper Cover
19	W10231485N	Trim, Crisper
20	12531202SP	Frame, Crisper
21	12204821	Glass, Crisper
22	W10273463	Ladder, Center
23	W10569182	Ladder, Side
24	12990513	Screw
25	W10215666	Screw
26	12990512	Screw
27	12530805SP	Slide, Humidity Control
28	12655303	Bar, Temperature Control
29	W11427806	Drawer, Pantry
30	12655204	Knob, Temperature Control

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
31	12656813	Lid, Pantry
32	W11115782	Basket, Lower
33	W10150061	Divider, Basket (Lower)
34	W11115548	Basket, Freezer (Upper)
35	12709301	Divider, Pantry
36		Gear
	W10474716	Left Hand
	W10474715	Right Hand
37		Mount, Gear
	W10348259	Left Hand
	W10348260	Right Hand
38	W10905889	Assembly, Shelf
39	W10149389N	Lift, Bail Arm
40	W10802333	Shaft, Rack

OPTIONAL PARTS

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	W10134625	Apollo Grey
	W10917540	Midnight Grey
	511873	White Porcelain (2 oz.)
	4392899	Biscuit/Bisque

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	350939	Enamel, Black
	285006	Black
	350942	White Primer
	4392901	Biscuit/Bisque

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

MISCELLANEOUS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4 x 108")
	876370	Insulation (2 Pieces, 3" x 24" x 48")
	876305	Insulation Kit (14 Pieces, 3" x 24" x 48")
	978941	Insulation, Fiberglass (63 1/2" x 35 1/2" x 2 5/8")
	876029	Kit, Foam Slab (30" x 32 1/2" x 1 1/2")
	505587	Sealer, Mastic (1 Qt)
	503695	Cork, Sealer
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1 1/4 Oz.)
	833938	Kit, Terminal Connector
	8003RP	Kit, Water Inlet

TORX SCREW WRENCH

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	1117510	Torx Key