




Dishwasher

MODELS:

KDPM664KPS3 (Stainless)

KDPM664KBS3 (Black Stainless)


DOOR AND PANEL PARTS



DOOR AND PANEL PARTS

<u>Qty.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Qty.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Qty.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts:	5		Panel, Front (includes item 11)	12	W11438513	Screw, Black
	W11323304	Owners Manual		W11233313	Stainless	13		Toe Panel
	W11333312	Energy Guide		W11233314	Black Stainless		W11487733	Black
	W11333314	Tech Sheet	7	W11333315	Cover, Handle Pocket	14	W11254833	Screw
2		Arm, Hinge	8	W11333316	Insulation, Multi-Layer	15	3400000	Screw
	W11333318	Left Hand	9	W11333317	Insulation, Single Layer			
	W11333319	Right Hand	10	W11333318	Insulation, Front Panel			
3	W11333315	Cross Brace, Door	11	W11333319	Seal, Nut, Front Panel			
4	W11333317	Screw						
5		Access Panel						
	W11133319	Black						


CONTROL PANEL AND INNER DOOR PARTS



CONTROL PANEL AND INNER DOOR PARTS

Item No.	Part No.	Description	Item No.	Part No.	Description	Item No.	Part No.	Description
1		Console Assembly (Includes Insert)	10	W11080822	Inner Door Assembly	18	W11022734	Stud Vent
	W11496510	Block	11	W11080823	Seat Door Bottom	19	W11391508	Fuse, In-Line
2	W110256418	Screw	12	W110543441	Wiring Harness, Main (Includes Thermostat & Fuse)	20	W11326940	Jumper Door
3	W110808348	Jumper, Lt.				21	W10348408	Screw
4	W10711284	Screw	13	W11084887	Wiring Harness, Inner Door			
5	W11081534	Latch Assembly (Includes Switch)	14	W11080849	Dispenser Assembly			
6	W110848284	Control Electronic	15	W11080827	Seat Console/Door			
7	W11025634	Seat Vent (Also Order Gasket)	16	W11080885	Hanger Control			
8	3400071	Screw	17	W11036720	Vent Assembly (Includes Fan)			
9	W10348408	Screw			(Also Order Gasket)			


TUB AND FRAME PARTS



TUB AND FRAME PARTS

Item No.	Part No.	Description	Item No.	Part No.	Description	Item No.	Part No.	Description
1	W11122458	Tub Assembly (includes gasket)	13	W11036176	Float Switch	24	W11362501	Miscellaneous Parts Bag (Contains 2 Screws, 2 Clamps, & 2 Brackets)
2	W11225744	Base, Terminal Box	14	W11184382	Plug, Tub	25		Tub Mount, Third Level Rack
3	W11035386	Gasket, Tub	15	W11425970	Water Inlet Assembly	W1101573		Left Hand
4	W11425974	NUL Water Inlet	16	W11455388	Leg, Leveling	W11255425		Right Hand
5	W11050487	Strike, Latch	17	5373125	Wasket, Fringed Cup	26	W11536142	Heater Element Assembly
6	W11258374	Screw	18	3450014	Screw, Grounding	27	W11055533	Tub Mount, Upper Rack
7	W11165091	Seal, Cabinet	19	W15277003	Screw	28	3450032	Screw
8	W11025382	Drip Tray	20	W11225745	Cover, Terminal Box	29	W10920244	Mit. Tub
9	W11025383	Funnel, Overfill Protection	21		Side Support, Tub			
10	W11025388	Funnel Extension		W115325122	Left Hand			
11	3265145	Bracket, Undercounter		W10520120	Right Hand			
12	W11165063	Cover, Tub Corner	22	W11221821	Shield, Top Sound			
			23	W11132441	Terminal Block			


PUMP, WASHARM AND MOTOR PARTS



PUMP, WASHARM AND MOTOR PARTS

Item No.	Part No.	Description	Item No.	Part No.	Description	Item No.	Part No.	Description
1	W11122133	Pump Assembly	13	W10900337	Hose, Bottom	24	W11122351	Camp. Hose
2	W11254332	Isolator, Front Motor	14	W110335723	Motor, Drain	25	W110335151	Hose
3	W10331545	Diffuser, Inlet	15	W11121134	Hose, Drain	26	W110335143	Clp. Hose
4	W11254335	Hanger, Front Motor	16	W10333433	Disc, Diverter	27	W13455555	Camp. Hose
5	5T41232	Screw	17	W11025553	Bracket, Rear Motor	28	W110335237	Hose, Inlet
6	W10331547	Check Valve, Drain	18	W11413271	Fastener	29	W11235575	Camp. Hose
7	W11043455	Wash Arm Assembly	19	W11125174	Indicator, Optical/Wash	30	W11033554	Grate
8	W11103555	Filter Assembly	20	370445	Camp. Hose	31	371305	Camp. Hose
9	W10330333	Reg. Valve	21	W11153415	Bracket, Thermostat	32		Diverter Valve Motor (Not Serviced)
10	W11345225	Motor & Pump Assembly	22	W11153055	Thermostat (Included with Main Wiring Harness)	33	W11034555	Burns (Includes Seal and Diverter)
11	W11035553	Isolator, Rear Motor	23	W11033570	Fill Valve Assembly	34	W15753575	Capacitor
12	W11250335	Hose, Pressure				35	W10457002	Screw


UPPER WASH AND RINSE PARTS



UPPER WASH AND RINSE PARTS

<u>Item</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Item</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Item</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10374330	Feed Tube Assembly	4	W11174340	Upper Sprayer Assembly	6	W10852638	Retainer, Docking (2nd Level)
2	W11033638	Retainer	5	W10303455	Cover, Diverter	7	W10852639	Retainer, Docking (3rd Level)
3	W11033652	Sprayer, Third Level						


UPPER RACK AND TRACK PARTS



UPPER RACK AND TRACK PARTS

Item No.	Part No.	Description	Item No.	Part No.	Description	Item No.	Part No.	Description
1	W12847875	Distrack, Upper	7	W11441105	Track, Distrack	13	W11284812	Track Stop, Rear
2	W11312237	Clip, Stemware	8	W11266682	Handle, Distrack Front	14	W11049221	Wheel
3	W11100172	Leveler, Adjuster Arm	9	W11266687	Handle, Distrack Rear	17	W11376295	Screw
4	W11180603	Clip, Adjuster Arm	10	3741233	Screw			
5	W11357533	Button, Adjuster Arm	11	W11186522	Time Res. Fold Down			
6		Adjustment Assembly	12	W11173752	Clip, Pinch			
	W11268090	Left Hand	13	W11173753	Postoner			
	W11268095	Right Hand	14	W11084874	Track Stop, Front			


LOWER RACK PARTS



LOWER RACK PARTS

<u>Item</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Item</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Item</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11234324	Catchco, Lower	5	W12666272	Tine Row, Fold Down	9	W11262820	Handle, Catchco Front
2	W11133747	Wheel & Transport Assembly	6	W11266668	Retainer, Flex Row	10	W11266668	Handle, Catchco Rear
3	W11251738	Structure Sidel Assembly	7	W12666888	Tine Row, Siding	11	5741032	Screw
4	W11267178	Lid, Silverline Sidel	8	W11406375	Retainer, Siding Tine Row			

THIRD LEVEL RACK AND TRACK PARTS



THIRD LEVEL RACK AND TRACK PARTS

<u>Item</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Item</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Item</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11127727	Rack, Third Level	7	9741232	Screw	15	W11034874	Track Stop, Front
2	W11441105	Track, Dishrock	8	W11200101	Cap Guard	16	W11034872	Track Stop, Rear
3	W11134071	Hanger, Tube	9	W11057523	Sevenside Tray	17	W11040221	Wheel
4		Track Mount	10	W12330577	Bracket, Front Hanger			
	W11231345	Left Hand	11	W12330523	Drive Side Assembly			
	W11231348	Right Hand			Manifold			
5	W11382620	Handle, Dishrock	12	W11121885	Cover, Wash Tube			
		Front	13	W12331334	Tube, Wash			
6	W11233631	Handle, Dishrock Rear	14	W11278385	Screw			

OPTIONAL PARTS (NOT INCLUDED)

<u>Item No.</u>	<u>Part No.</u>	<u>Description</u>
	4355277	Sensor Kit
	W11381554	External Drain Hose, 12 FT.
	W1135511	Power Cord Kit (Straight)
	W1135514	Power Cord Kit (Right Angle)
	4355573	Steam Relief, Power Cord (Metallic)
	W1355155	Compression Hose Fitting, (Water Line)
	W10275535RE	Fill Hose Kit